





快速安装指南

1


- * 请根据如下图示核对包装箱内物品(各1件):
- * Please check the items in the package shown as below:






2




3






9x





4



- * 将打印硒鼓沿导轨装入打印机，沿箭头方向按压并听到“咔嚓”声音，完成安装。
- * Insert the print cartridge along the guides then push firmly until you hear a click assuring you the print cartridge is fully inserted.






5




6




6





Microsoft® Windows® 2000 / Windows Server® 2003/2008 /
Windows® XP / Windows® Vista



7



Microsoft® Windows Vista®/Windows®7/Windows Server®2008



补充信息

要了解有关以下主题的详细信息, 请查看打印机附带的随机光盘上的电子版用户指南:

- 故障排除信息
- 重要的安全通知和规章条例信息
- 详细的用户操作步骤

信息也可从以下网站获得:

<http://www.pantum.com>

Additional Information

See the electronic User Guide on the CD-ROM accompanied with the printer for more information on the following topics:

- Troubleshooting information
- Important safety notices and regulatory information
- Detailed user instructions

This information is also available at

<http://www.pantum.com>

公司名称: 北京奔图科技有限公司
地址: 北京市海淀区北四环西路66号
中国技术交易大厦A座20层
邮编: 100080
服务热线: 400-060-1888
010-62682040
公司网址: <http://www.pantum.com>

Company Name: Beijing Pantum Technology Co., Ltd.

Address: 20th Floor, Block A, China Technology Transaction Mansion, No. 66 West Road of the North 4th Ring Road, Hai Dian District, Beijing, 100080, P.R.C

Service Hotline: 400-060-1888
010-62682040

Website: <http://www.pantum.com>

© 2012 by Zhuhai Seine Technology Co., Ltd.

PANTUM