

选择来单提示功能图示



Beep Select :选择蜂鸣
No Beep :蜂鸣器不提示.
[Form]Beep After Printing :每页打印之后蜂鸣器鸣叫提示.
[Form]Beep Before Printing :每页打印之前蜂鸣器鸣叫提示.
[Report]Beep After Printing :每个文档打印之后蜂鸣器鸣叫提示.
[Report]Beep Before Printing:每个文档打印之前蜂鸣器鸣叫提示.

